



Darbi aan difaac hoose loo samayn.

Darbi la isticmaalay Bitumen membrane

Ka Difaac dhismahaaga cusbadda.

■ Kahortag cusbadda

- Ka Hortag qoyaanka iyo huurka
- Farsamada marinta oo sahlan



POLYCOAT

Bitumen emulsion paint

Polycoat markii asaaska dhismaha la mariyo wuxuu sameeyaa lakab adag, kasoo ka hortaga soo gudbida qoyaanka iyo uumiga.

Faa'idooyinka Laga Dhaxlo

- Shubka oo uu difaac adag u sameeyo
- Anti-fungal technology
- Qaabka isticmaalka oo sahlan



■ Ka hortaga qoyaanka

■ Ka hortaga biyaha

■ Waxaa ku jirta goon

Kahortag cusbadda adigoo isticmalaya maadooyinka casriga ah ee aan kuu hayno

Dhismaha oo aan biyo joojin loo samayn waxay sababi kartaa in cimriga dhismaha uu soo gaabiyo.

Adeegsiga maadooyinka casriga ah waxay ka caawinayaan in ay dhismaha laayadiiso kor u qaadiisaan, taasoo sababaysa inuu dhismuhu yeesho billic heer sare ah iyo cimri dheer.



Goobaha Loo isticmaalo

Bituplus Ultra Bitumen membrane waxaa loo farsameeyay inuu si heer sare ah iskaga caabiyo qoyaanka iyo cimiladda kala duwan, waxaana badanaa loo isticmaalaa goobaha hoos ku xusan:



Saqafyo



Barandooyin



Footing



Goobaha Qoyan



Dilaacyada Guryaha iyo sida looga Hortago

Waxaa Jira goobo dhisma ka tirsan oo u nugul dilaacayada sida tiirarka shubka iyo bulukeetiga meesha ay iska galaan, sidaas darteed waxaa lama huraan ah in laga hortago dilaaca dhismaha iyadoo la isticmaalayo qalab kala diwan sida midkaan hoos ku xusan:



Plashter Mesh

- Waxaa loo isticmaala dilaacayada ku yimaada inta u dhaxaysa bulukeetiga iyo beamka ama column-ka.
- Sidoo kale waxaa lagu dayac-tiraa dilaacayadda ku yimaada dhismaha.



Fiberglass Mesh

- Waxaa loo isticmaala salaaxmada si salaaxmadu ay u noqoto mid adag oo aan dilaac yeelan.



Angle Bead

- Waxaa loo isticmaala samaynta gees(xagal 90) oo siman.



PUNCTURE RESISTANCE



FLEXIBLE



EASY LAY